



NOTICE DE MONTAGE - INSTALLATION INSTRUCTIONS

Caches latéraux Royal Enfield 650

Side covers for Royal Enfield 650

Difficulté - Difficulty 1 / 5

Outils nécessaires - Tools required for assembly

- Clefs cliquet - clefs allen - outillage standard -
- Ratchets - allen keys - classic tools

Procédure - Process

Démonter le cache latéral d'origine de la moto.

Séparer la partie inférieure (en métal) de la partie supérieure (plastique).

Fixer à l'aide des vis fournies la partie inférieure sur le cache latéral BAAK.

Pour le cache BAAK gauche : Visser la patte de fixation à l'aide de la vis fournie M5x12 sur le plastique du passage de roue situé sous la selle. (voir photo)

Pour le cache BAAK droite : Récupérer les deux rondelles caoutchouc et les installer sur le cache BAAK.

Disassemble the OEM side covers from the bike.

Separate the lower part (metal) from the upper part (plastic).

With the furnished screws, assemble the lower part on the BAAK side panel.

For the BAAK left panel : Screw the fixation bracket with the furnished screw M5x12 on the mudflap situated under the seat. (see photo)

For the BAAK right panel : Take both rubber washers from the OEM side panel and install them on the BAAK side panel.



Caches supérieurs BAAK
BAAK upper covers

Patte fixation sur cadre + Vis M5x12
Frame fixation bracket + Screw M5x12

Rondelles caoutchouc
Rubber washers

4x Vis M6x16 + Ecrou + Rondelle
4x Screw M6x16 + Nut + Washer

Caches inférieurs d'origine
OEM lower covers

