



NOTICE DE MONTAGE - INSTALLATION INSTRUCTIONS

Passage de roue / support de plaque pour Triumph Thruxton 1200 / Speed Twin 1200 License plate holder kit for Triumph Thruxton 1200 / Speed Twin 1200

Difficulté - Difficulty 1 / 5

Outils nécessaires - Tools required for assembly

- Clefs cliquet torx - outillage standard
- Ratchets torx - classic tools

Procédure - Process

Commencer par retirer la selle, puis débrancher le connecteur du feu arrière, dévisser le boîtier ECU, le soulever et retirer le câble de la serrure de selle ainsi que le faisceau de leurs encoches de maintien.

First remove the seat, then unplug the tail light connector, unscrew the ECU, lift it and remove the seat lock cable as well as the wiring harness from their retaining slots.



Dévisser les vis du garde-boue et prenant soin de ne pas le faire tomber.

Retirer les vis du garde-boue mais laisser en place les entretoises et caoutchoucs d'origines.

Remove the rear mudguard screws taking care to don't let it fall.

Remove the mudguard screws but leave the EOM spacers and rubbers in place.



- Si vous avez choisi l'option "**plaque en position arrière classique**" : Monter le support de plaque sur le passage de roue à l'aide des entretoises hexagonales et des vis M6x10 en serrant fermement. Faire passer les fils de l'éclairage de plaque et des clignotants si besoin à travers le caoutchouc, puis installer l'ensemble sur la moto.

- Si vous avez choisi l'option "**plaque en position latérale**" : Monter les entretoises hexagonales et les vis M6x10 en serrant fermement puis installer le passage de roue sur la moto.

Serrer sans exagération les vis du passage de roue, sans oublier les vis de L'ECU.

- If you have chosen the option "**License plate in classic rear position**" : Mount the license plate holder on the wheel arch using the hexagonal spacers and the M6x10 screws, tightening firmly. Route the license plate lighting and indicators wires if necessary through the grommet, then install the assembly on the motorcycle.

- If you have chosen the option "**License plate in side position**" : Mount the hexagonal spacers and the M6x10 screws tightening firmly, then install the wheel arch on the motorcycle.

Tighten the wheel arch screws without exaggeration, without forgetting the ECU screws.



(Le feu arrière n'est pas le bon sur les photos.)
 (The Tail light is not the good one on this photos.)

